





# Thermostats A Complete Guide






# Airzone Blueface



**Airzone Blueface thermostat**  
with 3.5" capacitive display

✓ VAF, ZBS and Easyzone Systems

Available in: 



— Capacitive icons (touch screen)      — Informative icons

<sup>1</sup>Options available depending on the configuration and/or the HVAC system  
For more information, you can consult the manuals at [www.airzonecontrol.com/support/](http://www.airzonecontrol.com/support/)


Airzone  
Think



**Airzone Think thermostat**  
with 2.7" e-ink screen

✓ VAF, ZBS and Easyzone Systems

Available in: 



— Capacitive icons (touch screen)      — Informative icons

<sup>1</sup>Options available depending on the configuration and/or the HVAC system  
For more information, you can consult the manuals at [www.airzonecontrol.com/support/](http://www.airzonecontrol.com/support/)

# Airzone Lite



**Airzone Lite** thermostat with capacitive buttons and a LED RGB light code

✓ VAF, ZBS and Easyzone Systems

Available in:  

## If the status LED is steady

The zone in which the thermostat is located is on.

## If the status LED is blinking


If the LED blinks slowly, it means that the zone in which it is located is off. It can be turned on again by pressing the LED or from remote zones.

If the LED blinks rapidly in red or purple, it means that there is an error. You can check this on the Airzone Blueface or using the Airzone Cloud app.

## If the status LED is off

The thermostat is in energy saving mode. In the case of the Airzone wireless Lite thermostat, this will happen by default. If it is a wired Lite thermostat, you can configure this parameter in *Lite settings* through remote zones from your Airzone Blueface thermostat or using the Airzone Cloud app.

The set-point temperature is the desired temperature. The default base temperature is 73°F and configured from the *Lite settings* parameter through remote zones from your Airzone Blueface thermostat or using the Airzone Cloud app.



— Capacitive icons (touch screen)

For more information, you can consult the manuals at [www.airzonecontrol.com/support/](http://www.airzonecontrol.com/support/)



**Airzone North America Corporation**

1800 SW 1st Ave. Suite 203. Miami FL 33129

[airzonecontrol.com](http://airzonecontrol.com)



MSTAZX6NSTNA02 | March 2022 Edition

The specifications in this catalog are valid except for typographical errors and may be subject to change without prior notice due to our continuous product improvement efforts. No part of this catalog may be reproduced without the express authorization of Airzone Clima S.L. The content of this catalog is the intellectual property of Airzone Clima S.L.